

Index

A	Spareparts
3-9	Caterpillar®, Volvo®
B	Steel Undercarriage
9	Link assies for medium and big machines
10	Grouser Shoes
11	Everpads®
12	Link assies for mini machines
13	Sockets and segment groups
14	Rollers
15	Idlers
C	Rubber Tracks
16	Features
17	Sizes
18	Patterns
D	Ground Engaging Tools,
19 f.	GET reference guide
23	Caterpillar®, tips
24	Caterpillar®, adapters
25	Bofors®, B-Lock
26	Bofors®, Topedo
26	Uni-Z®
27	Esco®, series 6
27	Esco®, Heli-Lock
28	Esco®, Conical
29	Lehnhoff®
30	Bolt on tips
31	Clamp shell tips
31	Zettelmeyer
32	Compact mini tips
33	HDL
33	Atlas
34	Wedl on safetyhooks
34	Sidcutters
35	Cutting edges
36	Wear bars
37	Plowbolts and nuts
E	Hensley®
38	about Hensley,
39	Bladesaver®2
40	Vertical Wear Shrouds
41	Vertical Wear shroud looks
42	weld on shrouds
43	Caterpillar®, Hensley® Style
44	Esco®, Hensley® Style
45	Parabolic, tips
46	Parabolic, adapters
F	Zubehör
47	Chisels
48	Buckets
49	Forks
50	Clamp shells

All names and reference numbers are used for identification purposes only. Subject to technical changes.

Inland: 02241 9449030, Fax: 02241 9449031 **Export:** +49 2241 9449040, Fax +49 2241 9449041
 Linser Industrie Service GmbH, Alleestr. 1, D-53757 Sankt Augustin, www.linser.eu
 Info@linser.eu